




E-LUMINATE

100" 16:9 Portable Projector Screen



INSTRUCTION MANUAL

Please read and retain these instructions for future reference.



CP201

HIGHLIGHTS

- 100" Screen Size
- 16:9 Aspect Ratio
- 180GSM Screen Polyester Fabric
- Carry Bag


PACKAGE CONTENTS

- Connex E-Luminate Portable Projector Screen 100"–16:9
- Instruction Manual

SPECIFICATIONS


- Portable and Foldable
- Convenient Carry Bag
- Screen Fabric: Elastic Polyester – 180GSM
- 160-degree Wide Angled View
- Transparent for Double-Sided Projection
- Black Framed Screen
- Viewing Area: 2214 x 1245mm (Open)
- Base Material: Iron
- G.W. : 3.2kg

ASSEMBLY PARTS




INSTRUCTIONS

1.



Use 4 x "A" tubes join together with spacers to assemble the top cross bar.
Use 4 x "A" tubes join together with spacers to assemble the bottom cross bar.

2.




Left

Right


Use 3 x "B" tubes join together with spacers to assemble left & right posts.

3.




Put the crossbar through the upper side of the screen.

3.




Insert and secure joints at both ends of the crossbar and the screen.

4.



Insert both posts through the screen and secure to the joints.

5.



Note: If applicable outdoors and please stable the screen with 4 stakes (Included) to solid ground to prevent screen fall down.

Insert both posts to the base and firmly lock up. Assembly is complete.

WARNING

The warranty will only be valid if you follow the instructions below carefully! Improper use and care may cause serious injury and / or damage!

Make sure the surface you have chosen for installing the screen is flat and secure.

Please read the following as any damage to the screen surface will impact the image's quality:

1. Do not touch the screen surface by hand.
2. Do not write or draw on the screen surface.
3. Do not poke the screen surface by finger or edge tools, as it may cause scratches or tears.
4. Do not pull two sides of the screen fabric by hands, do not fold the screen fabric.

To prevent unnecessary damage, the operation and maintenance of the screen should be done by adults.

Do not take apart and replace with unknown parts. If there are any problems, please contact your local dealer. Product specifications are subject to change.

WARRANTY

This Connex Projector Screen comes with a standard 12-month limited warranty against manufacturing defects and faults.

Should your Connex Projector Screen be unboxed with any faulty parts, poor finishing or visible damage, or fail to perform due to a manufacturing defect or poor workmanship, please return it with your proof of purchase (till slip or invoice) to the store of purchase for an exchange, or repair, depending on the store's returns policy.

This warranty commences from the date of purchase.

Kindly retain your proof of purchase as well as the packaging for your warranty period.

NOTE:

The warranty does not apply to a product that:

- a.) Has failed due to excessive wear and tear beyond what is considered to be reasonable.
- b.) Has been misused or neglected.
- c.) Has been damaged accidentally or by Force Majeure including fire and flooding.
- d.) Has been used or operated contrary to operating or maintenance instructions outlined in this manual.

The Store of Purchase / Seller cannot accept any returned products that have not been returned in accordance with this warranty or which does not follow their own Returns Policy. Please refer to the Store of Purchase / Sellers Returns Policy for details.